

BRACKETS ARE FOR FABRICATORS THAT ARE EXPERIENCED INSTALLERS

There are no specific instructions for brackets. Experienced installers know what to do. Always tack-weld the bracket in place, and run the airspring thru its cycle before PERMANENTLY WELDING. If welding onto the axle, you will burn thru the axle if you do not know what you are doing.

Use a [Schrader Valve](#) to test the cycle before final welds

MEASURE TWICE, CUT ONCE

01 \$15 Lower Circles	02 \$15 Top Circle	03 \$129 Upper/Lower wibags	04 \$49 Lower bag Cups U specify how tall	05 \$49 Upper Cups any U specify how tall	06 \$119 310 Dual Cups	07 \$119 Ranger 98-up cups	08 \$119 Dodge Front 02-up	09 \$119 Dodge Front 74-83
10 \$69 U-Build 5" Cup kit	11 \$119 Angled Front	12 \$19 \$19 \$22 \$26 Rings Weld Circles to Rings Shorten the circle, the lower your drop point	13 \$299 C10 Front Brackets	14 \$299 GM73-80 Lower wibags	15 \$299 GM81-87 Up/Lo	16 \$109 F150 or Range	17 \$299 F150 or Ranger	
18 \$299 F150 Wibags 97-03	19 \$299 Toyota 84-95	20 \$299 VW Bug 98up Rear	21 \$299 Nissan Front 87-97	22 \$299 Nissan Front 98-up	23 \$299 Isuzu Front 88-95	24 \$399 Toyota Airarms	25 \$399 58-64 Impala	26 \$399 55-57 Tri-5 Chevy
27 \$329 Spring Pocket Eliminators This device goes to the top of the spring and is bolted to the top of the spring. It is made of 1/2" steel and is 4" wide. It is 4" high. It is made of 1/2" steel and is 4" wide. It is made of 1/2" steel and is 4" wide. It is made of 1/2" steel and is 4" wide.	28 \$299 Torsion Trucks	29 \$299 S10 Front with bags	30 \$299 Dakota Front 87-up	31 \$299 Mazda 86-93	32 \$299 PT Cruiser rear	33 \$299 GM88-98 Front	34 \$299 Middle of Axle Rear	
35 \$299 Frame-Leaf 2.00" Mount	36 \$299 Frame-Leaf 2.50" Mount	37 \$99 4-Link upper bag	38 \$299 Middle Axle Brkt	39 \$299 DeepDrop Under Axle	40 \$299 Deeper Drop	41 \$299 Top of Axle		
43 \$299 Cross Axle wibags	44 \$299 top axle wishook mt	45 \$345 Basic Drop kit wibags Complete both sides	46 \$345 SuperBridge wibags	47 \$345 cross top bag mt	48 \$159 U-Bolt Plate 2.0" Spring	49 \$25 U-Bolt Plate 2.5" Spring	50 \$25 under frame brkt	51 \$159 under frame brkt
52 \$29 Upper Shock Tab	53 \$29 Shock mount kit	54 \$98 Shack-Kit	55 \$29 Bolt-on upper Stem Shock mount	56 \$9 Shock Studs	57 \$19 Shock Brackets	58 \$21 Adj 4-Link bar end 1-3/4" Studs	59 \$21 Adj 4-Link bar end 1-1/8" Stud Wizerk	60 \$21 Adj 4-Link bar end 1-1/8" Stud Wizerk
61 \$9 top frame brkt	62 \$9 4-Link Axle Tab	63 \$9 4-Link flat tab long	64 \$9 4-Link flat tab short	65 \$59 Under frame 4-Link	66 \$59 4-Link Bar Mounts	67 \$89 Lift bar axle brkts	68 \$59 Lower 4-link brkt	69 \$9 34-16 4-Link bung
70 \$299 Adj 4-link bar with bushings	71 \$219 Adj 4-link bar with Pivot	72 \$99 D-Bones	73 \$139 Adj D-Bones	74 \$59 Universal 4-Link Mount	75 \$39 4-Link bar gussets	76 \$12 4-Link end kit	77 \$39 4-Link Parallel tab	78 \$119 Panhard bar kit
79 \$19 1 1/8" Heim	80 \$12 1 1/8" 3/4"	81 \$149 S10 S15 S10 Bolt-on Diff With 4-Link mounts	82 \$149 any Mini Mini Differentials With 4-Link mounts	83 \$149 any /size C10 Bolt-on Diff & other Fullsize	84 \$139 Bolt-on Pavement Bridges	85 \$450 H2-Ex-Tension Front Upper weld to frame	86 \$12 4-Link Bar end	87 \$289 AirStrut Conversion Use your factory struts
88 \$99 Adjustable Hoops w/Order 22" \$230 24" \$260 26" \$290 Weld Covers only \$99 each	89 \$29 Most Models w/plate	90 \$159 Tailgate Skins	91 \$39 Tailite Covers	92 \$139 10 Gauge 8-pcs 4-pc C-Bridge	93 \$599 Factory Mounts All Vehicles Direct Bolt-on Struts	94 \$799 Colorado	95 \$12 4-Link Bar end	96 \$75 Cylinder Bracket Kit

